


GE SB 48-IN NEON FLEX LED SANTA

ASSEMBLY INSTRUCTIONS

NHL Model No.82005LO



Assembly Parts




Step 1: Insert part B into C according to the figure, and tighten the screw to lock. Connect the male and female power cables.

Step 2: Insert B into part D according to the figure, and tighten the screw to lock. Insert the hook into the hole.


Step 3: Insert part A into B according to the figure, and tighten the screw to lock. Connect the male and female power cables.

Step 4: Fix the four stakes at D and C according to the figure.


Step 1




Step 2




Step 3



Step 4



Assembly Complete




GE SB 48" NEÓN FLEXIBLE SANTA

INSTRUCCIONES DE ENSAMBLAJE

NHL Modelo No. 82005L0



Piezas de ensamblaje




Paso 1: Insertar la parte B en C de acuerdo con la figura, y apretar el Tornillo a cerrar. Conecte los cables de alimentación macho y hembra.

Paso 2: Insertar B en la parte D de acuerdo a la figura, y apretar el Tornillo a cerrar. Inserte el gancho en el agujero.


Paso 3: Insertar la parte A en B de acuerdo con la figura, y apretar el Tornillo a cerrar. Conecte los cables de alimentación macho y hembra.

Paso 4: Fije las cuatro estacas en D y C según la figura.


Paso 1




Paso 2



Paso 3



Paso 4



Ensamblaje completado

