




INSTRUCTION MANUAL FOR BLUETOOTH AND REMOTE CONTROL

CONTROL MODES: Bluetooth mode and RF (radio frequency) mode are two independent mode features and can only be used one mode at a time.

A. Bluetooth Mode:


Android & iOS system applicable. Operation: switch tree "ON". Turn on Bluetooth on your smart device and choose "Nicolas" to pair. When pairing is successfully made, you can now play music from your device.

1. Turn on Bluetooth on your smart device (iOS/Android).
2. Select "Nicolas" to connect. After pairing successfully, you can turn on your own music mode.
3. Open your music APP (iOS/Android).



B. RF (radio frequency) Mode:

Remote control is included in the product package. Remote control has various light effects & music functions.



Notes:

1. Bluetooth mode uses music from your device to play with the lights of the tree, so the 9 remote control functions will be unavailable under this mode. Bluetooth automatically disconnects when RF remote control is used.
2. Tree lights will change according to the default music or correspond to the music from the Bluetooth device.
3. Remote control includes **7 colors, 64 functions** and **8 pattern** combinations.
4. Each key corresponds to the chart below. Continue pressing the same key to cycle through all color selections.

Function Color	① Fade	② Twinkle	③ Flash	④ Dual Color	⑤ Chasing	⑥ Steady	⑦ Combo	⑧ Music	⑨ Volume
Red	•	•	•	• Warm white multi combo	• All Colors	•	• Auto	• All Music	• High
Green	•	•	•	• R/Gr	• Multi Chasing	•	• Layer Cascade	• Jolly Old Saint Nicholas	• Mid
Purple	•	•	•	• W/Bl	• R/G/W Chasing	•	• Up-down Wave	• 12 Days of Christmas	• Low
Blue	•	•	•	• W/R	• Patriotic Chasing	•	• Warm white multi combo	• Ding Dong Merrily On High	/
Gold	•	•	•	• Gr/Bl	/	•	• 3-speed Layer Chase	• Deck the Halls	/
White	•	•	•	• R/Go	/	•	• Warm white combo	• Carol of the Bells	/
Cool White	•	•	•	• Pu/Bl	/	•	• Multi combo	• We wish you a Merry Christmas	/
Multi	•	•	•	• W/Multi	/	•	/	• Nutcracker	/
Patriotic	•	•	•	/	/	•	/	• Jingle Bells	/

GE is a trademark of General Electric Company and is under license by Nicolas Holiday Inc.

Questions, call customer service toll-free at 1-877-398-7337 or visit us on web at www.geholidaylighting.com

Nicolas Holiday Inc.
9 F., No. 37, Guangfu North Rd.
Taipei, Taiwan 10560
All rights reserved.